Vigó Presses

Champagne and Wine Corker (code 97204)

Contents:

- Front leg (one foot)
- Rear Leg (two feet)
- Handle extension
- 4 large nuts and bolts (for legs)
- 2 smaller nuts and bolts (for handle)
- 3 square plastic feet stoppers
- 2 black plastic screw nuts
- 1 red plastic slider

Assembling:

1. Fix the front leg onto the main unit using 2 of the larger nuts and bolts.
2. Attach the rear legs. This is one piece that fixes onto the upright using two of the larger nuts and bolts.
3. Push the plastic plugs into the bottom of three feet. This can be done before or after attachig legs.
4. Stand the device up and attach the handle using the two smaller screws.
5. Screw the black screws onto the two fixed threads underneath the 'brass jaws section'. This will hold the red slider in place.
6. Fix the red slider between the black nuts with bottle neck holder pointing down. This is adjusted to hold wine or champagne bottle top in place when corking.